

Get the most out of your simulator purchase with the latest version of SimControl - including vital updates and new functionalities.

• Trainer & Platform Features

- New PRO5 Enhanced Graphics Features - Weather and time of day transitions, rocks within digging material for loaders
- RealView™ Operator View Calibration
- Search and Filter the Simulation Log - Show specific operator errors and events

• Surface Mining Features


- Light Vehicle Configuration Options - select from tray back or passenger LV, loaded or unloaded vehicle
- 'Incident in Convoy' Event for Light Vehicles
- Haul Truck Improvements - park-up accuracy metrics/assistants and new machine event

• Underground Mining Features

- New Light Vehicle Operator Errors - 4WD engaged or disengaged inappropriately
- Sandvik Underground Loader Enhancements - traction control system tuning and park brake
- Audio Cues Improved for Underground Trucks and Loaders

• Increased Autonomous Functionality

- Komatsu FrontRunner® Autonomous System - Additional machine support, training events and operator errors
- Cat® Command for Hauling - Larger Rom Dump B tip head, dozing available at additional locations and a range of new training events



Australia: +61 8 9347 9000

Email: Support@ImmersiveTechnologies.com

Visit: www.ImmersiveTechnologies.com/SimControl